


Constellation™ Management Software for Transmitters (CMX-MGT)



SMTP Management Window

Content	Page
ABOUT THIS DOCUMENT	3
1 SOFTWARE OVERVIEW	5
1.1 Revision History	5
1.2 Basic Network Capabilities	5
1.3 Network Application Protocols	5
1.4 Software Features	6
1.5 Basic Network Requirements	6
2 DEVICE NETWORK DISCOVERY	6
2.1 mDNS and AutoIP	6
2.2 IP Discovery via mDNS	7
3 ACCESS	8
3.1 Web UI Login	8
3.2 HTTPS Web Access	8
4 STATUS	9
4.1 Status Page	9
4.1.1 Device Name	9
4.1.2 Device Details	10
4.1.3 Channel Status	11
4.1.4 System Details	11

(continued)

Content	Page
4.1.5 Faults	13
4.2 Channel Grouping	13
4.2.1 Creating a Channel Group	13
4.2.2 Possible Channel Group Statuses	14
4.2.3 Automatic Grouping	14
4.2.4 Obtaining Channel Details	15
4.2.5 Channel Fault Details	16
5 HISTORY	16
5.1 Choosing a History Date Range	17
5.2 FCSV Export	17
6 EVENTS	17
7 POLICY	18
7.1 Available Policy Actions	18
7.2 Policy Examples	19
8 SETTINGS	20
8.1 General	20
8.2 Account	21
8.3 Users	21
8.3.1 User Access Control	22
8.3.2 External Authentication and Access Control (RADIUS)	23
8.4 Network	25
8.5 Alerts	25
8.6 Webhooks	26
8.7 Watchdog	27
8.8 SMTP	27
8.9 SNMP	28
8.10 Date & Time	29
8.11 RADIUS	29
8.12 Software Update	30
8.13 Firmware Update	31
8.14 Diagnostics	32
8.15 Factory Reset	32
9 LIGHTING	32
9.1 Nominal and Max Current Limits	32
9.2 Default Output State (Lighting Only)	32
9.3 Enhanced Fault Tolerance (Lighting Only)	33
10 TROUBLESHOOTING AND RECOVERY PROCEDURES	33
10.1 Software API	33
10.2 Software Recovery Mode	33
10.3 Constellation Management Module (MGT500E) Software LED	35
11 HARDWARE BUTTONS	36
11.1 Factory	36
11.2 Reboot	36

ABOUT THIS DOCUMENT

REVISION HISTORY

This is the original version of this document.

TRADEMARKS

CommScope (logo), CommScope, and Constellation are trademarks of CommScope, Inc.

LIST OF ALL CONSTELLATION PRODUCTS

[Table 1](#) lists all currently available Constellation products with catalog numbers and Material IDs (MIDs).

Table 1. Constellation Products

PRODUCT	CATALOG #	MID
Power Transmitter	CPCX-12	760254285
Management Module	CTX-MGT	760254286
Power Supply	CPM-3K	760254287
Transmitter Card	CTX-6	760254288
Multi-Chassis Synch Card	CMX-6	760254289
SAF D to L620P Cord	CABLE-PWR SAFD-L620P	760254290
C19 to L620P Cord	CABLE-PWR C19-L620P	760254291
C19 to 5-15P Cord	CABLE-PWR C19-515P	760254292
Power Transition Panel	CPT-PP-48C	760254293
Power Patch Cable	CTX-CBL-10	760254294
Powered Backplane	CPCB-1	760252855
Edge Enclosure	CPCE-1	760252854
TBD	HFPC	TBD
Power Supply Bay Cover	PM500-COVER	760254642

LIST OF ALL CONSTELLATION PUBLICATIONS

Table 2 lists technical publications available for the Constellation system. These manuals can be accessed online using the QR code on the product packaging or by contacting the CommScope Support Center at <https://www.commscope.com/SupportCenter>

Table 2. Constellation Technical Publications

Publication Title	Publication #
Constellation Power Transition Panel (CPT-PP-48C) User Manual	TC-96343-IP
Constellation Transmitter Card (CTX-6) Data Sheet	TC-96344-IP
Constellation Power Supply (3PM-3K) Data Sheet	TC-96345-IP
Constellation Multi-Chassis Synch Card (CMX-6) Quick Start Guide	TC-96346-IP
Constellation Power Supply Bay Cover (PM500-COVER) Data Sheet	TC-96347-IP
Constellation Management Software for Transmitters User Manual	TC-96349-IP
Constellation Edge Enclosure (CPCE-1) With Powered Backplane (CPCB1) User Manual	TC-96350-IP
Constellation Best Practices Guide	TC-96351-IP
Constellation Power Transmitter (CPX-12) Quick Start Guide	TC-96354-IP

CONTACT INFORMATION

- To find out more about CommScope® products, visit us on the web at www.commscope.com
- For technical assistance, customer service, or to report any missing/damaged parts, visit us at <http://www.commscope.com/SupportCenter>

1 SOFTWARE OVERVIEW

This section lists the software and networking features of the management software for CommScope's Constellation Power Transmitter (CPCX-12) and related products including:

- Power Supply (CPM-3K)
- Transmitter Card (CTX-6)
- Multi-Chassis Synch Card (CMX-6)
- Power Transition Panel (CPT-PP-48C)
- Powered Backplane (CPCB-1), and
- Edge Enclosure (CPCE-1).

1.1 Revision History

The first software release for this software is version 1.0.0.

The latest software release is version 1.X.X (October 2022.) For software upgrade questions, contact <http://www.commscope.com/SupportCenter>

1.2 Basic Network Capabilities

- 10/100 Bps Ethernet interface
- IPv4 static and DHCP addressing
- IPv6 link-local and Global addressing

1.3 Network Application Protocols

- HTTP
- HTTPS with self-signed certificate (since v1.4)
- mDNS
- SNMP v1 and v2c
- DNS
- NTP
- SMTP+TLS
- RADIUS

1.4 Software Features

- Control, management, and administration via web UI
- Local user authentication with user access roles
- Scheduled and hardware-triggered policy rules
- Local logging of power, fault, and events
- REST/JSON API
- 6 months of data retention
- CSV history export
- Remote software & firmware updates
- Push notification via HTTP/S webhooks
- Email notifications via SMTP+TLS
- SNMP v1 and v2c GET, SET, & traps
- RADIUS user authentication + RBAC

1.5 Basic Network Requirements

The Constellation Management Software for Transmitters requires the following network elements to be present at the installation site in order for the software to operate correctly:


- IPv4 via DHCP (default) or static IPv4 address, or IPv6 via Ethernet,
- Access to some DNS server (set by DHCP option 6 in IPv4 DHCP mode),
- Access to some NTP server for accurate event time stamping and TLS certificate validation. The device uses a set of public NTP servers by default.

2 DEVICE NETWORK DISCOVERY

2.1 mDNS and AutoIP

In order to access the software, the device's network address must be known. Out of the box, the device uses DHCP to make it "plug-and-play" with most IP-based networks. There are several ways to discover the assigned IP address of a device, which are described here.

Network Discovery can be done via the Constellation Discovery Tool or "tool-less" via mDNS. The recommended approach is using the Constellation Discovery Tool, shown in [Figure 1](#), for quick acquisition of all devices on the network, as shown below.




VOLTSEVER DISCOVERY TOOL (1.3.0.0)							
Search by Hostname, Serial, or MAC Address							
voltsevr-0000	103998041801	2002:4857:5d6d:1:564a:16ff:feb1 192.168.8.193	54:4a:16:bb:00:00	1.3.0	0d 13:20:56	ETX8	Connect
voltsevr-3b91	106600000236	2002:4857:5d6d:1:f684:4cff:fe1f 192.168.8.103	f4:84:4c:1f:3b:91	1.3.0	0d 13:20:53		Connect
voltsevr-4209	106600000229	2002:4857:5d6d:1:f684:4cff:fe1f 192.168.8.184	f4:84:4c:1f:42:09	1.4.0-dev	0d 02:32:16		Connect
voltsevr-46dd	106600000129	2002:4857:5d6d:1:564a:16ff:feb1 192.168.8.172	54:4a:16:c2:46:dd	1.2.0	0d 13:20:54		Connect
voltsevr-d3bf	106600000246	2002:4857:5d6d:1:f684:4cff:fe09 192.168.8.233	f4:84:4c:09:d3:bf	1.4.0-dev	0d 13:20:51		Connect

Figure 1. Discovery Tool for Windows

2.2 IP Discovery via mDNS

If a device's hostname is already known, its IP address can be discovered via mDNS. The default hostname and MAC address are printed on the label on the side of each device.

A routable IP for the device can be discovered by running "ping [hostname].local" as shown in Figure 2.



```

C:\WINDOWS\system32>ping cs-6838.local

Pinging cs-6838.local [fe80::7a04:73ff:fe55:6838%21] with 32 bytes of data:
Reply from fe80::7a04:73ff:fe55:6838%21: time<1ms
Reply from fe80::7a04:73ff:fe55:6838%21: time<1ms
Reply from fe80::7a04:73ff:fe55:6838%21: time<1ms
Reply from fe80::7a04:73ff:fe55:6838%21: time=1ms

Ping statistics for fe80::7a04:73ff:fe55:6838%21:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 1ms, Average = 0ms

C:\WINDOWS\system32>

```

Figure 2. Ping Test

Note: By default, the device hostname is **cs-XXXX** where **XXXX** are the last 4 characters of the device's MAC address. For example, if the device's MAC ends with **68:38**, the default hostname will be **cs-6838**

Test network connectivity to the device by opening a command prompt and running **ping [hostname].local**

If the device is connected directly from a laptop/PC to its Ethernet port (for example, “crossover cable”), the “`ping [hostname].local`” command will discover the device’s AutoIP (169.254.x.x) address.

3 ACCESS

3.1 Web UI Login

Most user interaction with the software will occur via the web interface hosted on the device. To access, open “`http://constellation-XXXX.local`” or “`http://[ip address of the device]`” in a supported browser. The login page, shown in [Figure 3](#), will appear:



Figure 3. Device Login Page

The factory-programmed password can be found on the unit label on the rear or side of the device. The default username is **admin**.

3.2 HTTPS Web Access

The device also provides access via HTTPS, using a self-signed certificate. Because it is not possible for browsers to trust a self-signed certificate, a warning will appear the first time the HTTPS page is opened.

4 STATUS

4.1 Status Page

All “real-time” device telemetry is displayed on the Status page, shown in [Figure 4](#), including:

- Device name (editable)
- Total system power
- System faults
- Device serial, MAC, and IP addresses
- Channel number and editable channel name
- Channel power, status, faults
- Channel analog set point (lighting only)
- Channel uptime




Figure 4. Status Page

4.1.1 Device Name

The device name may be changed by clicking on it, as shown in [Figure 5](#).



Figure 5. Changing the Device Name

4.1.2 Device Details

Network and device details are visible in the top right quadrant of the Status page, as shown in Figure 6.




Figure 6. Device Serial Number, MAC Address, and IP Address

4.1.3 Channel Status

Name, power, uptime, and output/live ID status can be seen for each channel, as shown in [Figure 7](#). If this is a lighting product, output “level” control is also present.

CHANNEL	NAME	POWER & STATUS	OUTPUT	LIVE ID
1	Channel 1	27 w 40d 21h 53m	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
2	Channel 2	14 w 16d 21h 16m	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
3	Channel 3	15 w 16d 21h 16m	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
4	Channel 4	Disconnected (0101)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Figure 7. Channel Status

4.1.4 System Details

Detailed status can be found by clicking the “System Details” button located on the Status page within the INFO box, as shown in [Figure 8](#).

INFO	
SERIAL	112599000002
MAC ADDRESS	40:BD:32:EB:A0:F3
IP ADDRESS	10.61.187.246

Figure 8. System Details Button

The system details display in a window such as shown in [Figure 9](#).

Transmitter							
SERIAL NO.	FIRMWARE HARDWARE	POWER	BACKPLANE VOLTAGE	INPUT VOLTAGE	CURRENT	TEMPERATURE	MGT STATUS
112599000002	2.4.0 2.0.0	58 W	336000 mV	117000 mV	175 mA	58°C	0

Channels											Show DEQ
SLOT	LABEL	SERIAL NO.	FIRMWARE HARDWARE	POWER	VOLTAGE (mV)	CURRENT (mA)	TEMP (°C)	MODE	MAJOR STATUS	MINOR STATUS	
1	Channel 1	1037000001	2.0.0 2.0.0	28 W	335400	85	37	Source Enabled (2)	0x0	0	
2	Channel 2	1037000002	2.0.0 2.0.0	14 W	335700	43	37	Source Enabled (2)	0x0	0	
3	Channel 3	1037000003	2.0.0 2.0.0	15 W	335400	47	36	Source Enabled (2)	0x0	0	
4	Channel 4	1037000004	2.0.0 2.0.0	0 W	0	0	36	Delay Source (32)	0x0101	0	
5	Channel 5	1037000005	2.0.0 2.0.0	0 W	0	0	34	Delay Source (32)	0x0101	0	
6	Channel 6	1037000006	2.0.0 2.0.0	0 W	0	0	34	Delay Source (32)	0x0101	0	
7	Channel 7	1037000007	2.0.0 2.0.0	0 W	0	0	35	Delay Source (32)	0x0101	0	
8	Channel 8	1037000008	2.0.0 2.0.0	0 W	0	0	35	Delay Source (32)	0x0101	0	

Power Modules							
SERIAL NO.	TYPE	INPUT VOLTAGE (mV)	OUTPUT VOLTAGE (mV)	OUTPUT CURRENT (mA)	TEMP (°C)	STATUS	ALARM
191050028645	AC (5)	117000	336300	200	36	1	0

Figure 9. System Details Window

This information may be useful for troubleshooting. At the top of the System Details table, there are three buttons:

4.1.4.1 Upload Button

Information about this device will be upload to CommScope and notify a CommScope Support technician.

4.1.4.2 Copy Button

System information is copied to the clipboard, or a dialog is opened to be manually copied and pasted.

4.1.4.3 Email Button

The user's default mail handler will open to compose a new email message to CommScope Support with system information automatically copied in the body of the email.

4.1.5 Faults

System status including MGT, channel, and power module faults are displayed within the Power & Status bar as shown for the “Disconnected (010)” message in [Figure 10](#).

CHANNEL	NAME	POWER & STATUS	OUTPUT	LIVE ID
1	Channel 1	27 w	40d 21h 53m	<input checked="" type="checkbox"/> <input type="checkbox"/>
2	Channel 2	14 w	16d 21h 16m	<input checked="" type="checkbox"/> <input type="checkbox"/>
3	Channel 3	15 w	16d 21h 16m	<input checked="" type="checkbox"/> <input type="checkbox"/>
4	Channel 4	Disconnected (010)		<input checked="" type="checkbox"/> <input type="checkbox"/>

Figure 10. Fault Displayed in Power Status Column

4.2 Channel Grouping

Channel grouping is used when more than one channel is connected to the same receiver. [Figure 11](#) shows a channel group composed of Channel 2 and Channel 3.

Channel 1 TRANSMITTER

SYSTEM POWER

52

MGT OK CHANNEL OK POWER MODULE OK

INFO

SERIAL 11259900002

MAC ADDRESS 40:BD:32:EB:A0:F3

IP ADDRESS 10.61.187.246

System Details ⓘ Create Group

GROUPS ALL CHANNELS

STATUS	NAME	POWER & STATUS	OUTPUT	LIVE ID
OK	Constellation	24 w	OFF ON	OFF ON
2	Channel 2	12 w	5d 22h 14m	<input checked="" type="checkbox"/> <input type="checkbox"/>
3	Channel 3	12 w	5d 22h 14m	<input checked="" type="checkbox"/> <input type="checkbox"/>
UNGROUPED CHANNELS				
1	Channel 1	26 w	39d 5h 34m	<input checked="" type="checkbox"/> <input type="checkbox"/>

Figure 11. Channel Group

4.2.1 Creating a Channel Group

Channel groups can be manually created from the status page. Click the “Create Group” button in the upper right of the window. A dialog will appear ([Figure 12](#)).




Figure 12. Channel Group Dialog

Give the group a name (usually name of the load or location), and select which channels are in the group. Only group channels that are connected to the same DE receiver.

4.2.2 Possible Channel Group Statuses

Table 3 shows the possible statuses for a channel group.

Table 3. Constellation Channel Group Statuses

STATUS	DESCRIPTION
OK	All channels in the group are delivering power to the load
Degraded	At least one channel in the group is disconnected or faulted, but other channels continue to deliver power
Outage	No channels in the group are delivering power
Mixed	One or more channels in the group are turned off but all other channels are delivering power

4.2.3 Automatic Grouping

Automatic grouping (Auto-Grouping) can attempt to infer channel groups based on channel slot and load information as shown in the example in Figure 13. Note auto-grouping only works for enabled (connected, not faulted) channels. The auto group feature provides a list of suggested groupings. The user may choose which groups to create from the auto-group suggestion




Figure 13. Auto Grouping

4.2.4 Obtaining Channel Details

Clicking on any channel name or number from the Status page will show the channel detail page shown in Figure 14. Recent events, power data, and present channel status can be viewed on this page. The channel name may be edited by clicking on the name in the upper left, in the same manner as editing the transmitter name on the main page.




Figure 14. Channel Details Page

4.2.5 Channel Fault Details

If the Channel Details page is open and the channel is faulted, fault information and troubleshooting steps will be displayed as shown in [Figure 15](#):




Figure 15. Channel Fault Details

5 HISTORY

All device history is stored for a maximum of 6 months on local persistent storage. History is retained through reboots, power loss, software updates, and so on. Events older than the retention period are periodically purged to preserve storage space. The history page displays power over time charts for the unit and each channel. See the example in [Figure 16](#).



Figure 16. History Page

5.1 Choosing a History Date Range

When viewing the History and Events pages, by default, the most recent data is displayed and will live-update. To view older history, uncheck “LIVE UPDATE,” then choose the desired “FROM” and “TO” date range, then click “Update.”




Figure 17. History Date Range

5.2 FCSV Export

After selecting a date range, you may click the “Export CSV” button to download data in a format that can be manipulated in Excel. Note that exports are limited to 500 rows for each data type.

6 EVENTS

The Events page displays a list of channel faults and system events.

The screenshot shows the 'Events' page interface. At the top, there is a 'LIVE UPDATE' toggle which is currently turned on. Below it, the 'FROM' date is set to 'Dec 15, 2019 2:53 PM' and the 'TO' date is set to 'Dec 16, 2019 2:53 PM'. A note below the date pickers says 'Uncheck «Live Update» to pick date range'. To the right of the date pickers are 'Update' and 'Export CSV' buttons. Below the date pickers are two tabs: 'Faults' and 'System', with 'System' selected. Below the tabs is a 'USE TRANSMITTER TIMEZONE' toggle which is currently turned off, with the text 'America/New_York' next to it. Below the toggle is a table with the following columns: STATUS, TYPE, DATE, MESSAGE, COUNT, and LAST OCCURRENCE.

STATUS	TYPE	DATE	MESSAGE	COUNT	LAST OCCURRENCE
	System	12/16/2019 2:49:14 PM	New hardware found; chassis s/n: 106600000388	1	12/16/2019 2:49:14 PM
	System	12/16/2019 2:49:14 PM	New hardware found; MGT s/n: 106600000388	1	12/16/2019 2:49:14 PM
	System	12/16/2019 2:49:14 PM	Power module 10000000001 was inserted	1	12/16/2019 2:49:14 PM
	System	12/16/2019 2:49:14 PM	Application started	1	12/16/2019 2:49:14 PM
	System	12/16/2019 1:47:55 PM	Local user 'admin' [::ffff:127.0.0.1] logged in	1	12/16/2019 1:47:55 PM

Figure 18. Events Page

The application records the following events:

- Channel faults and output toggle events
- Channel group faults and output toggle events (non-lighting products only)
- System faults
- Network events (IP address assigned/ changed)
- SNMP traps sent
- Software reboot
- Factory reset
- Power module inserted or changed
- Software update started, completed, and failed
- Firmware update started, completed, and failed
- User log-in/ log-out

7 POLICY

Policies may be created to instruct the device to perform actions based on input events or a time schedule.

7.1 Available Policy Actions

- Fade channel output (lighting only)
- Set channel group output (non-lighting only)
- Log system event message
- Send email
- Delay (pause between actions)

Events

LIVE UPDATE

FROM: Dec 15, 2019 2:53 PM TO: Dec 16, 2019 2:53 PM Update Export CSV

Uncheck «Live Update» to pick date range

Faults System

USE TRANSMITTER TIMEZONE America/New_York

STATUS	TYPE	DATE	MESSAGE	COUNT	LAST OCCURRENCE
	System	12/16/2019 2:49:14 PM	New hardware found; chassis s/n: 106600000388	1	12/16/2019 2:49:14 PM
	System	12/16/2019 2:49:14 PM	New hardware found; MGT s/n: 106600000388	1	12/16/2019 2:49:14 PM
	System	12/16/2019 2:49:14 PM	Power module 10000000001 was inserted	1	12/16/2019 2:49:14 PM
	System	12/16/2019 2:49:14 PM	Application started	1	12/16/2019 2:49:14 PM
	System	12/16/2019 1:47:55 PM	Local user 'admin' [::ffff:127.0.0.1] logged in	1	12/16/2019 1:47:55 PM

Figure 21. UPS Battery Backup Policy

8 SETTINGS

8.1 General

The device can be configured to display a non-default name for labeling purposes, as shown in the example in Figure 22. There are three configurable fields: **label**, **organization**, and **site**. Each field can be used as grouping or other logical identifiers and will be displayed in the web page's navigation bar.

SETTINGS

- General
- Account
- Users
- Network
- Alerts
- Webhooks
- Watchdog
- SMTP
- SNMP
- Date & Time
- RADIUS
- Software Update
- Firmware Update
- Diagnostics
- Factory Reset

General Settings

These fields are *optional* and may be used to show identifying information in the header of this local user interface. They can also be used for tagging, aggregation and identification by network monitoring or management systems.

Unit Label Constellation 1

Organization CommScope


Site Address, Building, Venue, Installation, etc.

Apply Changes

Figure 22. General Settings

8.2 Account

The Accounts page, shown in [Figure 22](#), is used to add or edit a User and assign a User role. This page is available to the system administrator for every user and is available to a non-administrative user for the associated account only.



The screenshot shows a web interface for managing user accounts. On the left is a sidebar menu under the heading 'SETTINGS' with options: General, Account (highlighted), Users, Network, Alerts, Webhooks, Watchdog, SMTP, SNMP, Date & Time, RADIUS, Software Update, Firmware Update, Diagnostics, and Factory Reset. The main content area is titled 'User MY ACCOUNT' and contains the following fields: 'Username' with the value 'User', 'Email' with the value 'user.name@commscope.com', 'Role' with a dropdown menu set to 'Admin', 'Password' (masked with dots), and 'Confirm Password'. A blue 'Apply Changes' button is located below the password fields.

Figure 23. Account Page

8.3 Users

An administrator may create, view, edit, or delete local user accounts. Multiple accounts may be used either for auditing purposes or to provide multiple access levels to the device.

The “session timeout” may also be configured. This controls how long an idle session remains logged in. The default value is 60 minutes. The minimum session timeout is 5 minutes.

The Users Settings page, shown in [Figure 24](#), also displays active user sessions including remote IP address and last activity.

The screenshot shows the 'Users' settings page. On the left is a sidebar with 'Users' selected. The main area has a 'Create new user' button and a table of users:

USERNAME	EMAIL	ROLE	RADIUS?	ACTIONS
admin	--	Admin		[edit] [delete]
shawnbasic	--	Basic		[edit] [delete]
Roland	roland.menge@commscope.com	Admin		[edit]

Below the table is the 'General User Settings' section with a 'Session Timeout (minutes)' field set to 60 and an 'Apply Changes' button. At the bottom, there is an 'Active Users' section with a refresh icon and a table:

USER	REMOTE IP	LAST ACTIVITY
Roland	::ffff:10.67.0.212	Tue Dec 20 2022 6:18:39 PM

Figure 24. Users Settings Page Showing Three Local Users and a RADIUS User

8.3.1 User Access Control

Multiple users may be created with one of the following access roles: **admin**, **operator** and **basic**. The following matrix outlines what software capabilities are allowed for each role.:

Table 4. User Access Control

FEATURE	ADMIN	OPERATOR	BASIC
View status page (real time inventory)	X	X	X
View channel status	X	X	X
View device history	<u>X</u>	<u>X</u>	<u>X</u>
View fault events	X	X	X
View system events	X	X	
Change device name	X	X	
Change channel name	X	X	
Change channel outputs	X	X	
Toggle channel live ID	X	X	
View policies	X	X	X
Create, edit policies	X	X	
Enable or disable policies			
Change own password	X	X	X
Change own email	<u>X</u>	<u>X</u>	<u>X</u>

Table 4. User Access Control

FEATURE	ADMIN	OPERATOR	BASIC
View users / sessions	X	X	
Create user	X		
Edit user	X		
Create / edit alerts	X	X	
Change / view webhook settings	X		
Create / view hostname	X		
Change / view network settings	X		
Change / view NTP settings	X		
Change / view SMTP settings	X		
Change / view SNMP settings	X		
Change / view RADIUS settings	X		
Change / view SSH settings	X		
Change / view fault handling settings	X		
Change / view lighting settings	X		
Change diagnostic reporting	X		
Perform factory data reset			
View software version			
Perform software update			
View firmware version			
Perform firmware update			
Create / edit / delete a channel group			
View channel group status			
Toggle channel group outputs			
Toggle channel group live ID			
Change external watchdog settings			
Pet external watchdog			

8.3.2 External Authentication and Access Control (RADIUS)

An administrator may configure the device to delegate AAC to a local RADIUS server, using the “PAP” or “CHAP” authentication. When RADIUS is enabled, all user logins that do not match a local account will be sent to the RADIUS server. If the server gives an “Access-Accept” response, the requesting user will be logged in.

If the RADIUS server provides a “Session-Timeout” attribute in the “Access-Accept” response, the device will automatically re-authenticate the user’s credentials after that many seconds. If no

“Session-Timeout” attribute is given, the device will re-authenticate with the RADIUS server every 5 minutes while the user is active.

To grant the Operator or Admin role to a RADIUS user, add the “Filter-Id” attribute with a value of “admin” or “operator”. If no Filter-Id is attribute is sent, the user is granted “Basic” access.

Prior to v1.8.0, devices used the “Cisco-AVPair” VSA to designate role access. This method should be considered deprecated in favor of the standard Filter-Id attribute starting in v1.8.0.

CHAP authentication was added in v1.8.0.

Figure 25. RADIUS Authentication Settings

Note: RADIUS user settings (name, email, role, password) cannot be modified from the “Users” settings page

Figure 26. RADIUS Managed View

8.4 Network

Hostname and static IPv4 address may be changed if desired using the Network Settings page shown in [Figure 27](#),

Figure 27. Network Settings Page

If settings are changed, the browser will redirect to the new IP address or hostname after settings are applied. You will likely be required to login to the web UI again after an IP address or hostname change.

IPv6 addressing is not configurable via the user interface: by default, a link local address is assigned, and the device will also negotiate a global address if a prefix is advertised via IPv6 RA.

DNS

DNS access from the device is strongly recommended as it may be used for various other network facilities such as SMTP and NTP server name resolution. When configured for DHCP, the device expects to receive a list of DNS servers via DHCP option 6.

8.5 Alerts

The Email Alerts page may be used to identify configured to send email alerts to SMTP server as is shown in [Figure 31](#). The device supports TLS encryption for SMTP connections.




Figure 28. SMTP Settings With TLS

8.6 Webhooks

Devices can send fault events and periodic telemetry readings to automated event handling and system monitoring services using HTTP/S webhooks. When enabled, the device will send an HTTP POST with a JSON payload describing the event and identifying information of the device.

Figure 29 shows the Webhooks page.




Figure 29. Webhooks Page

Use the “Send test” button to send a test payload for validation. A local system event will be logged if Webhooks fail to be sent (e.g. due to network failure.)

Faults webhooks are sent, at most, once every 5 seconds, with a maximum of 50 faults in a single request. If a webhook request fails, the failed webhook will be retried with exponential back off to a

maximum of 10 minutes between retries. Multiple fault webhooks may be configured, one per line to a maximum of 20 destinations.

Readings are pushed every 5 minutes to a single destination. Reading webhooks are not retried if a request fails.

8.7 Watchdog

The external watchdog is a failsafe feature that, when enabled, turns off the outputs of all channels if an external application (typically the VoltServer hosted app) loses connectivity to the unit for an extended period of time. This feature is disabled by default and should not be enabled except in applications approved by VoltServer Support team.

The External Watchdog setting is disabled by default.




Figure 30. External Watchdog

8.8 SMTP

The device may be configured to send email alerts to SMTP server as is shown in [Figure 31](#). The device supports TLS encryption for SMTP connections.

Use the “Test Connection” button to validate credentials and network reachability before applying settings.

Once an SMTP server is configured, alert recipients may be added, and a test email can be sent:

Note: Alerts are sent for Channel Faults and System Faults only.

A local system event will be logged if the device fails to send an SMTP alert (for example, due to network issues.)

Alerts are sent at most once every 30 seconds, with a maximum of 20 events (most recent.) One alert email is sent with all enabled recipients in the “To” field of the email. The subject line of the alert message will read “Constellation alert for device <hostname>”. If the device fails to send the request to the SMTP server (configured below) the alerts will remain enqueued and retry with a 5 second delay until the server is reached.

SETTINGS

- General
- Account
- Users
- Network
- Alerts
- Webhooks
- Watchdog
- SMTP**
- SNMP
- Date & Time
- RADIUS
- Software Update

SMTP Settings

Host:

User:

Password:

Port:

From:

Secure (TLS Enabled)

Figure 31. SMTP Settings With TLS

8.9 SNMP

The software supports SNMPv2c and SNMPv1 for GET, SET, and Inform operations, according to the COMMScope-CONTROLLER MIB. Traps are sent for channel and system faults. See supplementary SNMP integration package for MIB details and packet capture samples. SNMPv2c is selected by default. [Figure 32](#) shows the SNMP Settings page.

SETTINGS

- General
- Account
- Users
- Network
- Alerts
- Webhooks
- Watchdog
- SMTP
- SNMP**
- Date & Time
- RADIUS
- Software Update
- Firmware Update
- Diagnostics
- Factory Reset

SNMP Settings

Enabled Get, Set and GetNext requests will be IGNORED

Contact:

Location:

Community:

Trap Destinations:

Trap Type: SNMPv2 (inform) SNMPv1 (trap)

Download MIB

Figure 32. SNMP Settings

Send Test Trap

Use the “Send Test Trap” button to validate trap destinations. This will send up to four separate alarms (v2 inform or v1 trap, depending on the chosen setting) to each trap destination specified. The alarms are:

- mgtFaultAlarm
- txCardFaultAlarm

- txGroupStatusAlarm (for group supported devices)
- powerModuleStatusAlarm

This may be used to test both network reachability to the trap destinations as well as parsing by the trap recipient.

8.10 Date & Time

By default, the device is configured to sync to public, load-balanced NTP servers from ntp.org. If using DHCP, the device will also sync to an NTP server specified by DHCP option 042. Network access to an NTP server is strongly advised in order to ensure accurate timestamps of readings, faults, and system events.

If no NTP servers are reachable, device date/time can be set manually.

The device date and time can be viewed, as well as present timezone and NTP sync status.

The screenshot displays the 'Date & Time Settings' page. On the left is a navigation menu with 'Date & Time' selected. The main content area includes:

- NTP Servers:** A text area with a hint 'Enter one server name per line' containing two entries: '0.time-a-g.nist.gov' and '1.time-a-wvv.nist.gov'.
- Timezone:** A dropdown menu set to 'Central: Chicago'.
- Apply Changes:** A blue button.
- Date/Time & NTP Status:** A dark grey box showing:


```
Local time: Tue 2022-11-08 15:11:32 CST
Universal time: Tue 2022-11-08 21:11:32 UTC
RTC time: Tue 2022-11-08 21:11:33
Time zone: America/Chicago (CST, -0600)
System clock synchronized: yes
NTP service: active
RTC in local TZ: no
```
- Manual Date & Time:** A yellow warning box stating: 'Manually setting the date/time is not recommended except when no time sync server is accessible on the network. Note that without NTP sync, the device clock will likely lose accuracy over time due to factors such as clock drift and power loss. If no NTP server is available you can manually set the device date & time here.' Below this is a 'Date & Time' input field showing 'Nov 8, 2022 3:11 PM' and a 'Set Date & Time' button.

Figure 33. Date & Time Settings Page

8.11 RADIUS

An administrator may configure the device to delegate AAC to a local RADIUS server, using the “PAP” or “CHAP” authentication. When RADIUS is enabled, all user logins that do not match a local

account will be sent to the RADIUS server. If the server gives an “Access-Accept” response, the requesting user will be logged in.

If the RADIUS server provides a “Session-Timeout” attribute in the “Access-Accept” response, the device will automatically re-authenticate the user’s credentials after that many seconds. If no “Session-Timeout” attribute is given, the device will re-authenticate with the RADIUS server every 5 minutes while the user is active.

To grant the Operator or Admin role to a RADIUS user, add the “Filter-Id” attribute with a value of “admin” or “operator”. If no Filter-Id attribute is sent, the user is granted “Basic” access.

Prior to v1.8.0, devices used the “Cisco-AVPair” VSA to designate role access. This method should be considered deprecated in favor of the standard Filter-Id attribute starting in v1.8.0.

CHAP authentication was added in v1.8.0.

Figure 34. RADIUS Authentication Settings

Note: RADIUS user settings (name, email, role, password) cannot be modified from the “Users” settings page

8.12 Software Update

Software updates can be performed without interrupting Digital Electricity power. Select an update file provided by CommScope support, then click “Update:”




Figure 35. Software Update

Note: While performing software updates, certain software functions such as policy, event logging, alerting, and programmatic (API) access may be temporarily unavailable. The software will automatically restart when the update completes. The user will be prompted to re-login.

8.13 Firmware Update

Device firmware may be updated via the web interface. Select an update file provided by VoltServer support. The application will indicate which components may be upgraded with the given firmware package depending on hardware compatibility. Select the components to be updated, and then click “Begin Update”.




Figure 36. Firmware Update

8.14 Diagnostics

Error reporting is disabled by default. When enabled, if the device encounters an unexpected error, it will attempt to securely send an error report to **CommScope**, for support and quality improvement purposes. All error reports are transmitted over HTTPS/TLS and do not contain any sensitive information. To enable this behavior, check the “Error reporting” box on the Diagnostics page, then click “Apply Changes.”




Figure 37. Diagnostic Settings

8.15 Factory Reset

The device can be factory reset to its “out of the box” state using the “Factory Data Reset” button. All settings will be restored to their defaults. All user data including policies, channel groups, names, users, events and reading history will be deleted. The user will be required to re-login using the factory default username and password after performing a factory reset.

9 LIGHTING

ETX8-SA-277 lighting units have additional settings to configure the current limits used on the device. These settings can be set via the “Lighting” settings page. Note these settings should not be changed from VoltServer recommended values based on your lighting system design. Improperly setting these values could result in damage to light fixtures.

9.1 Nominal and Max Current Limits

These settings must be correctly set based on the type and configuration of lighting fixture used. Consult VoltServer support before setting or changing these values.

9.2 Default Output State (Lighting Only)

The default output state option allows changing the default DE output behavior on power up

Table 5. Constellation Technical Publications

ACTION	RESULT
Output Stays Off	All DE outputs will be off until turned on via user control or API
Turn on	All DE outputs will turn on to the last nonzero set point
Restore last set point	All DE outputs will turn on to the last set point before power loss (including off, if a channel was off before power loss.)

The factory default option is “Output stays off.”

This feature was added in v1.7.0.

9.3 Enhanced Fault Tolerance (Lighting Only)

When enabled, enhanced fault tolerance works to minimize flickering and faults that may occur at certain intensity levels. Note that this feature trades off intensity range for fault avoidance and should not be enabled except on units with channels that are prone to transmission faults.




Figure 38.

10 TROUBLESHOOTING AND RECOVERY PROCEDURES

10.1 Software API

All software capabilities outlined in this document are exposed via REST API. API authentication uses the same account credentials as GUI user logins. See the supplementary API documentation for full details.

10.2 Software Recovery Mode

In the exceptional event that the software becomes corrupted or the module otherwise fails to boot normally, the device may enter recovery mode. This is visually indicated by a “Blue heartbeat” on

the “SW” LED of the Constellation Management Module (CTX-MGT)(See [MGT500E Software LED<XREF>](#)). In this state, the device will revert to its default hostname that is printed on the product label and use IPv4 DHCP addressing and mDNS (e.g. should be accessible at <http://voltserver-XXXX.local> where XXXX is the last two bytes of its MAC, in hex.) The following web page will be visible while the device is in recovery mod



Figure 39. Software Recovery Mode

While Recovery Mode is active, the device will open SSH port 4222, username root, password d1g1ta1P0wer to facilitate performing a system upgrade. This should not be performed except when a full system wipe is required.

Recovery Mode may also be entered during power up: Immediately after power-on or software reboot, hold the “Factory” button for 5 seconds. On MGT500E, recovery mode is indicated by a blue “heartbeat” blink pattern on the “SW” LED.

To leave recovery mode, simply reboot the device without holding the “Factory” button.

If a device continues to enter recovery mode without pressing the “Factory” button during boot, please contact [CommScope](#) support.

10.3 Constellation Management Module (MGT500E) Software LED

The Constellation Management Module (MGT500E) has a “SW” LED that indicates the present status of the software.

LED PATTERN	LED PATTERN	NOTE
BLU 	5 s after power-on.reboot	Software module power-on and pre-boot. Pushing “Factory” button during this time causes device to boot in Recovery Mode
GRN 	30 s (approximately)	Software is booting (green “heartbeat” blink pattern)
GRN 	Until reboot	Software is running
BLU 	20 s (approximately)	Factory reset is in progress
BLU 	Until reboot	Software is in recovery mode (blue “heartbeat”)

11 HARDWARE BUTTONS

The Constellation Power Transmitter (CPCX-12) has two physical buttons recessed behind the front panel. Buttons may be pressed using a thin implement such as a paperclip or multimeter probe.

11.1 Factory

The “Factory” button performs a factory reset and restores all settings to factory defaults, including network settings, user accounts, and deletes all history data from the device. To perform a factory reset, press and **hold the “Factory” button for at least 3 seconds**. Reset will begin when the button is released. Starting with software version 1.6.0, the “SW” button on the MGT500E will display a “fast blue” blink while the reset is in progress. At the end of the factory reset procedure, the software will reboot.

11.2 Reboot

The “Reboot” button causes the software to reboot. This is a software-only reboot and does not reset any hardware conditions.