



CRFK Ladder Rack Foot Kit Instructions

General

The CRFK ladder rack foot kit includes the CRBSK butt splice kit to attach the foot brace to the ladder rack section.

Ordering information is listed below:

Material ID	Part No.	Description
760084020	CRFK	CRFK ladder rack foot kit

How to Contact Us

- To find out more about **CommScope®** products, visit us on the web at <http://www.commscope.com/>
- For technical assistance:
 - Within the United States, contact your local account representative or technical support at 1-800-344-0223. Outside the United States, contact your local account representative or Authorized Business Partner.
 - Within the United States, report any missing/damaged parts or any other issues to **CommScope** Customer Claims at 1-866-539-2795. Outside the United States, contact your local account representative or Authorized Business Partner.

Parts List

Verify parts against the parts list below:

Quantity	Description
2	Foot braces
1	CRBSK butt splice kit (see CRBSK instruction sheet)
1	Instruction sheet

Tools Required

- 9/16" socket and driver or open-end wrench

Installation

